

Tannin Index - Tablet Count

Reagents and Equipment


Please use reagent pack **RGPK015** – includes:

Tannin No. 1 Tablets – **AT008**

Tannin No. 2 Tablets – **AT009**

Capped sample container

Method



1. Filter sample if necessary to obtain a clear solution.
2. Add 50ml of sample to the flask or container.
3. Add two Tannin No 1 tablets, cap the container and shake until the tablets disintegrate.
4. Add one Tannin No 2 tablet, cap the container and shake until the tablet disintegrates.
5. Continue adding Tannin No 2 tablets one at a time in this manner until a pink colour persists for approximately one minute.
6. Note the number of Tannin No 2 tablets used and calculate the result from the formulae below :-

Tannin Index= Number of Tablets x 2

or

Tannin (mg/l) = Number of Tablets x 20